

COLOR IMAGE QUALITY

The *Kodak i1400 Series* Scanners produce excellent color image quality, however, these scanners do not support color management between devices (i.e., between monitor, scanner and printer.)

Judgment of color is highly subjective. Here are some things to consider when scanning in color:

- The difference in the color outputs of scanners, printers, and monitors can affect the perception of the scanned document.
- Computer displays and printer output can vary from model to model, and from manufacturer to manufacturer. An image may be acceptable on one display and unacceptable on another.
- Area lighting (fluorescent, natural, incandescent) can affect color perception.
- The appearance of a colored area within an image can be perceived differently, based on what surrounds it. The characteristics and condition of a document can have an impact on color consistency.
- Color requirements may differ between environments (e.g., in a business document environment, images are generally viewed on a monitor, whereas in a “print on demand” environment, scanned images are printed).

Supplies*

Supplies/Consumables	CAT No.
<i>Kodak</i> Feeder Consumables Kit for i1400 Series Scanners	124 1066
<i>Kodak</i> Extra-Large Feeder Consumables Kit for i1400 Series Scanners	821 5808
<i>Kodak</i> Imaging Guide Set (1 upper guide, 1 lower guide)	120 0278
<i>Kodak</i> Printer Ink Cartridges (10)	135 5155
<i>Kodak</i> Printer Ink Blotters (60)	840 5425
<i>Kodak</i> Printer Ink Cartridge Carrier	826 7486
Staticide Wipes for <i>Kodak</i> Scanners (144)	896 5519
<i>Kodak Digital Science</i> Transport Cleaning Sheets (50)	169 0783
<i>Kodak Digital Science</i> Roller Cleaning Pads (24)	853 5981
Calibration Target (12" x 12")	127 1436
<i>Kodak</i> White Background Accessory	829 3599
<i>Kodak</i> Black Background Accessory	854 6079
<i>Kodak</i> i1400 Series A3 Flatbed	179 6747

* Items are subject to change.

Kodak i1400 Series Scanners



Quick Tips

www.kodak.com

Kodak Field Service
1-800-356-3253

Kodak Technical Assistance
1-800-822-1414

Kodak Professional Services
1-800-525-6325

EASTMAN KODAK COMPANY
343 State Street
Rochester, New York 14650
© Kodak, 2006 TM: Kodak
A-61551
PN 9E4700

Kodak

www.kodak.com/go/docimaging

Cleaning and Maintenance

For detailed cleaning and replacement procedures, see the *Maintenance* chapter in the User's Guide.

Opening/closing the scanner cover

1. Turn off the scanner.
2. Lift up the scanner cover release to unlatch the scanner cover.



3. Pull up to open the scanner cover.
4. Close the door when finished cleaning internal components or replacing parts.
5. Turn on the scanner.

FEED MODULE

Cleaning and replacing the feed module

1. Open the scanner cover.
2. Push against the raised edge on the left side of the front roller cover to the side and pull the cover up and out to remove it.



NOTE: You may need to lift the input tray slightly to remove the front roller cover.

3. Remove the feed module by pushing it to the right and lifting it out.



4. Manually rotate and wipe the feed module rollers with a roller cleaning pad.
5. Inspect the feed module. If the feed module tires show signs of wear or damage, replace the tires or the feed module.
6. Remove any dust or debris from the tray area under the feed module and front roller cover.
7. Insert the new feed module by aligning the pins and pushing it toward the right to fit it into position.
8. Reinstall the front roller cover.

SEPARATOR MODULE

Cleaning and replacing the separator module

1. Open the scanner cover.
2. Grasp the separator module and lift it up and out of position.
NOTE: The separator module fits tightly in place, therefore, you may need to pull hard to release it.
3. Manually rotate and wipe the separator module tires with a roller cleaning pad.
4. Inspect the tires. If the separator tires show signs of wear or damage, replace the tires or the separator module.
5. Insert the new separator module and align the shaft ends..



6. Press until the separator module clicks into place.

PAPER PATH

1. Remove the wrapping from the Transport Cleaning Sheet.
2. Adjust the side guides to fit the cleaning sheet.
3. Feed the cleaning sheet (adhesive side up) through the scanner in portrait orientation until all residue is removed from the drive rollers.
4. Adjust the sides guides to fit, feed the cleaning sheet (adhesive side up) through the scanner in landscape orientation until all residue is removed from the drive rollers.
5. Using the same cleaning sheet, repeat Steps 3 and 4, but feed the cleaning sheet through the scanner adhesive side down until all residue is removed from the drive rollers.

NOTE: When the cleaning sheet gets dirty, discard it and use a new one.

IMAGING GUIDES

Cleaning the imaging guides

Clean the exposed (top side) surfaces of the imaging guides. You do not need to remove the imaging guides for cleaning unless there is dust or dirt on the underside of the imaging guide.

1. Open the scanner cover.
2. Allow the scanner to cool, with the lamps off, for 5 minutes before proceeding.
3. Wipe the upper and lower imaging guides with a Staticide wipe.
NOTE: The i1410 Scanner does not have an upper imaging guide.
4. Dry the imaging guides with a dry Staticide wipe.
5. Lower the scanner cover and press it down firmly until it latches into place.

To do a more thorough cleaning, remove the imaging guides. Refer to the instructions in the *Maintenance* chapter of the User's Guide.

IMPORTANT:

- *The Roller Cleaning Pad contains sodium lauryl ether sulfate and sodium silicate which can cause eye irritation.*
- *Staticide wipes contain isopropanol which can cause eye irritation and dry skin. Wash your hands with soap and water after performing maintenance procedures.*

Refer to the User's Guide for MSDS acquisition.