



Quick Connect Guide

for LCD HDTVs

1

Verify Box Contents

Power cable, remote control, two batteries, user manual and warranty card

Identify Connections

Please see chart to the right to determine video quality

Base Removal

See instructions in the user manual

2

Connect external source devices

Indicate devices used in the Notes column


Connect RF Antenna

If using a cable or settop box, skip channel scan

Power on TV

Connect power cable to wall outlet
Press power button on keypad or remote

Follow On-Screen Setup Menu



3

Power on external source devices

Press input button on remote

Use input list to select source device

Setup and verify external source devices

Enjoy your new Westinghouse TV!

*For DVD combo models insert DVD and go!



We recommend using HD programming for the best viewing experience!



Optimal day or night viewing



Easy side cable access




Organized cable management

Quick Connection Reference

PT Series	Source Devices							Notes
	TV Input	Over-the-air	Cable/Satellite	DVD HD-DVD Blu-ray	Game Console	VHS	PC	
HDMI		N/A	Best	Best	Best	N/A	Best	
VIDEO + LR Audio		N/A	Good	Good	Good	Good	N/A	
VGA + Audio Mini Jack		N/A	N/A	N/A	N/A	N/A	Best	If Available
ANT		Best	N/A	N/A	N/A	N/A	N/A	



Customer Service
866-287-5555



Wall Mounts
Go to www.wde.com to see which Westinghouse mounts are compatible with your LCD TV.



Go to www.wde.com to check out the complete line of Westinghouse LCD products.